

# ACHTUNG

## vor dem ersten Gebrauch

- Bitte überprüfen Sie die Backspringform auf Mängel. Bei Mängeln, diese unverzüglich, dem Verkäufer melden.
- Bitte entsorgen Sie die Verpackung und die Packungsbeilage recyclinggerecht.
- **Kinder niemals unbeaufsichtigt, ohne Eltern oder volljährige Personen, mit der Backspringform lassen!**
- Reinigen Sie die Backspringform vor dem ersten Gebrauch mit heißem Wasser und gewöhnlichen Küchenschwamm. Keine Kratz- und Scheuermittel verwenden!
- Es wird empfohlen die Backspringform vor jedem Gebrauch mit Butter oder Margarine einzufetten.
- Bei Gebrauch immer mit Ofenschutzhandschuhen arbeiten, da Verbrennungsgefahr besteht.
- Backspringform ausschließlich im Backofen bis 230°C verwenden. Backspringform bis 230°C hitzeresistent.
- Backspringform für Mikrowelle, Grill oder direkte Hitzequellen nicht geeignet.
- Backspringform nicht auf heiße Herdplatte stellen/erhitzen.
- Backspringform nicht unbefüllt im Backofen erhitzen.
- Backspringform nur auf einem Gitterrost oder Backblech, mittig, im Backofen gebrauchen.
- Keine scharfen oder stumpfen Gegenstände z.B. Messer, Löffel, usw. darauf oder darin verwenden. Empfindliche Oberfläche!
- Nach Gebrauch Backspringform immer abkühlen lassen, bevor diese gereinigt wird. Im heißen Zustand nicht in kaltes Wasser eintauchen oder mit kaltem Wasser auffüllen.
- Nach Reinigung grundsätzlich abtrocknen, da sich Spülwasser oder Speisereste, am unteren Rand, ansammeln und somit zu leichten Roststellen/Verunreinigungen führen kann. Somit sind diese keine Materialfehler und beeinträchtigen die Funktionalität des Produktes nicht!
- **Reklamation nach erstem Gebrauch ausgeschlossen!**



-1- Irrtümer und Änderungen vorbehalten – 102021

Bread Bowl Baba

Germany

## ATTENTION

### Before First Using

- Please check the baking pan for defects. In case of defects immediately notify the seller.
- Please dispose of the packaging and the leaflet recycling-friendly.
- Never leave children unattended, without parents or adults, with the baking pan.
- Clean the baking pan with hot water and ordinary kitchen sponge before first use.
- Don't use any scratch or scouring agents.
- It is recommended to grease the baking pan with butter or margarine before use.
- Always use oven protective gloves when using, as there is a risk of burns.
- Only use the baking pan in the oven up to 446°F. Baking pan heat resistant up to 446°F.
- Baking pan for microwave, grill or direct heat sources not suitable.
- Don't place the baking pan on hot stove or heat.
- Don't heat the baking pan unfilled in the oven.
- Baking pan use only on a grate or baking tray, in the middle, of the oven.
- Don't use sharp or blunt objects, such as knives, spoons, etc. on or inside the baking pan.  
Sensitive surface!
- After use, let the baking pan cool down before cleaning it. When hot, don't immerse in cold water or fill with cold water.
- After cleaning, always dry, as rinse water or food particles, accumulate at the bottom and this can lead slight rusting or contamination. Thus, these aren't material defects and don't affect the functionality of the product!
- **Complaint excluded after first use!**



-1- Errors and changes excepted – 102021

Bread Bowl Baba

Germany